

# Instruments for measuring concentrations and emission rates of gases and particulates from animal feeding operations

This publication describes the operational characteristics of some commonly used instruments for measuring concentrations and emission rates of gases and particulates encountered in animal feeding operations (AFOs). Of special interest are the measurements of ammonia ( $\text{NH}_3$ ), hydrogen sulfide ( $\text{H}_2\text{S}$ ), and particulate matters (PM).

Integration of sophisticated analyzers and electronic devices, such as those listed in Table 1, Figures 1–10, may be used to measure multiple pollutants simultaneously and continuously. The mobile emission lab (MEL), Figure 11, with an estimated cost of \$125,000, is an example of such integration. MEL is used by researchers and regulatory agencies throughout the country to measure ambient concentrations as well as emission rates of carbon dioxide ( $\text{CO}_2$ ),  $\text{NH}_3$ ,  $\text{H}_2\text{S}$ , and PM. Another example of this methodology is the custom-fabricated monitoring devices that comprise commercially available sensors that may also be used in air-quality monitoring. The portable monitoring unit (PMU), Figure 12, with an estimated cost of \$3,000, was developed by Iowa State University researchers and is being used in a nationwide study of  $\text{NH}_3$  and  $\text{CO}_2$  emission from poultry facilities.

It should be noted that concentrations and emission rates are two different, although related, quantities. Concentrations measure the strength of the pollutant in the air or solution and have the unit of percent (%), parts per million (ppm), parts per billion (ppb), or parts per trillion (ppt). Emission

rates, on the other hand, measure the magnitude of pollutant release from the source, and have the unit of weight of pollutant per animal or body weight (e.g., 500 kg or 1,100 lb) per unit of time (e.g., minute, hour, day, or year). The two are related by the air exchange rate through the source. Namely, emission rate is the product of concentration and ventilation rate.

The importance of quality data on ventilation rate in determining the emission rate cannot be overemphasized. Assumption and use of published fan performance data under commercial operation conditions can be off by 10 to 50 percent. A quick but less accurate way to check airflow rate of a ventilation fan is to measure the average air velocity (traverse) with an anemometer, Figure 13, through the cross-sectional area of the fan and multiply it by the cross-section area. A newly refined device, referred to as fan assessment numeration system (FANS), Figure 14, costs \$10,000 (with trailer). The FANS allows users to calibrate actual fan airflow rate on site. The FANS has become a widely accepted and used instrument among researchers in AFO air emission studies.

The equation used to calculate emission rates based on concentration of the substance and local climatic conditions is given in Appendix A. Use of the equation also is illustrated by calculating  $\text{NH}_3$  emission rate from a manure-belt laying hen house in central Iowa.

Neither endorsement of companies, products, or services mentioned is intended, nor is criticism implied of similar companies, products, or their services not mentioned.

**Table 1. Instruments for measuring ammonia (NH<sub>3</sub>), hydrogen sulfide (H<sub>2</sub>S), and particulate matter (PM) concentrations**

Instrument Type	Detection Limit <sup>a</sup>	Uncertainty <sup>b</sup>	Response Time <sup>c</sup>	Data Type	Degree of Maintenance	Portability	Power Required	Vulnerability or Immunity	Approximate Cost	Suitability
<b>Ammonia (NH<sub>3</sub>)</b>										
Colorimetric tube (active or passive diffusion) (Fig. 1)	0.5 ppm	20–25% of reading	< 2 minutes	Snapshot or time integrated	N/A	Portable, easy to use	None		Tube: \$5–6 Pump: \$300	Indoor/outdoor ppm levels
Chem-cassette single point monitor (SPM) (Fig. 2)	3 ppm	20–25% of reading	> 10 seconds	Real time, continuous	Moderate	Fairly portable, weighs 15 lb	12 VDC, 110 VAC	Vulnerable to moisture interference	SPM: \$7,000 Tape: \$60–80 ea.	Indoor/outdoor ppm levels
Electro-chemical monitor (Fig. 3)	1 ppm	< 6% of reading	< 1 minute	Real time, continuous	Moderate	Portable, easy to use, weighs 0.5 lb	9 VDC	Vulnerable to sensor saturation from continuous NH <sub>3</sub> exposure	Base unit: \$500 Sensor: \$350	Indoor/outdoor ppm levels
Photo-acoustic multi-gas analyzer (Fig. 4)	0.2 ppm or lower	1% full scale	>13 s for single gas, and > 40 s 5 gases	Real time, continuous	Relatively low	Relatively portable, weighs 20 lb or less	110 VAC	May compensate for temperature, pressure, and moisture	\$10,000 for NH <sub>3</sub> only \$45,000 for five gases	Indoor/outdoor low-high ppm levels
Chemiluminescence analyzer (Fig. 5)	1 ppb	1% full scale	< 120 seconds	Real time, continuous	High	Not readily portable, weighs 60 lb	110 VAC	Immune to moisture interference	\$17,000	Indoor/outdoor, ppb-ppm levels



Figure 1. Colorimetric tube (active or passive diffusion)



Figure 2. Chem-cassette single point monitor



Figure 3. Electro-chemical monitor



Figure 4. Photo-acoustic multi-gas analyzer



Figure 5. Chemiluminescence analyzer

Instrument Type	Detection Limit <sup>a</sup>	Uncertainty <sup>b</sup>	Response Time <sup>c</sup>	Data Type	Degree of Maintenance	Portability	Power Required	Vulnerability or Immunity	Approximate Cost	Suitability
<b>Hydrogen Sulfide (H<sub>2</sub>S)</b>										
Colorimetric tube (active or passive diffusion) (Fig. 1)	0.5 ppm	20–25% of reading	< 2 minutes	Snapshot or time integrated	N/A	Portable, easy to use	None		Tube: \$5–6 Pump: \$300	Indoor/outdoor ppm levels
Chem-cassette single point monitor (SPM) (Fig. 2)	3 ppb	20–25% of reading	15 minutes	Real time, continuous	Moderate	Portable, weighs 15 lb	12 VDC, 110 VAC	Vulnerable to moisture interference	SPM: \$7,000 Tape: \$60–80 ea.	Indoor/outdoor ppb levels
Jerometer (Fig. 6)	3 ppb	1–2% full scale	< 30 seconds	Snapshot or real time, continuous	Moderate	Portable, easy to use, weighs 7 lb	12 VDC, 110 VAC		\$8,000	Indoor/outdoor ppb-ppm levels
Pulsed fluorescence analyzer (trace level) (Fig. 7)	0.06–0.75 PPB, depending on operating mode	The larger of 1% reading or 1 ppb	80–320 seconds	Real time, continuous	Moderate	Not readily portable	110 VAC	Immune to moisture interference	\$17,000	Indoor/outdoor, ppb-ppm levels
<b>Particulate Matter (PM)</b>										
Laser particle counter (LPC) (Fig. 8)	0.3 µm	10–15%	Immediate	Particle counts, not gravimetric	High when used in dusty conditions	Portable, easy to set up	12 VDC, 110 VAC	Contamination and hence instrument malfunction	\$4,000 or more	Indoor/outdoor low PM levels
Filtration (Fig. 9)	Depends on balance used	> 10%	Variable	Time integrated	Low	Portable, easy to set up	12 VDC, 110 VAC	Care in sample handling and weighing	Pump kit: \$800 Ready-to-use filters: \$65/50	Indoor/outdoor, low-high PM levels
Tapered electronic oscillation microbalance (TEOM) (Fig. 10)	0.01 µg	5.0 µg/m <sup>3</sup> (10 min average) 1.5 µg/m <sup>3</sup> (1-hr average)	10–60 minutes, depending on precision	Real-time, continuous	High	Not readily portable	110 VAC	Clogging in dusty conditions	\$18,000	Indoor/outdoor low-high PM levels

<sup>a</sup>Detection limit refers to the lowest level that the instrument is able to measure with the specified uncertainty.

<sup>b</sup>Uncertainty refers to the deviation of the measured value from the true value.

<sup>c</sup>Response time generally refers to the time needed for the instrument to register 90% or higher of the equilibrium value.




Figure 6. Jerometer



Figure 7. Pulsed fluorescence analyzer (trace level)



Figure 8. Laser particle counter



Figure 9. Filtration pump and filter



Figure 10. Tapered electronic oscillation microbalance

Neither endorsement of companies, products, or services mentioned is intended, nor is criticism implied of similar companies, products, or their services not mentioned.



Figure 11. Mobile emission lab



Figure 12. Portable monitoring unit



Figure 13. Anemometer



Figure 14. Fan assessment numeration system

## Appendix A. Equation and example of emission rate calculation

$$ER = Q \times (C_o - C_i) \times 10^{-6} \times \frac{W_m}{V_m} \times \frac{T_{std}}{T_a} \times \frac{P_a}{P_{std}}$$

where ER = emission rate, weight per unit time

Q = ventilation or air exchange rate through the building or source at field temperature and barometric pressure conditions, volume per unit time

$C_i$  = concentration of the pollutant at inlet of the building or source, ppm

$C_o$  = concentration of the pollutant at outlet of the building or source, ppm

$W_m$  = molar weight of the pollutant at standard temperature (0 °C) and pressure (101.325 kPa) or STP, g/mole (e.g., 17 g/mole for NH<sub>3</sub>)

$V_m$  = molar volume of the pollutant gas at STP, 22.4 L/mole

$T_{std}$  = standard temperature, 273.15 °K

$T_a$  = ambient temperature, (°C + 273.15) °K

$P_{std}$  = standard barometric pressure, 101.325 kPa

$P_a$  = ambient barometric pressure, kPa

**Example.** A manure-belt laying hen house located in central Iowa (elevation of 1,000 ft) contains 100,000 laying hens. The layer house is ventilated at 1.5 CFM per bird to maintain an indoor air temperature of 74 °F. Hourly average NH<sub>3</sub> concentration of incoming or fresh air and exhaust air is measured to be 0 and 4 ppm, respectively. Determine the hourly ammonia emission rate from the layer building.

**Step 1.** Building ventilation rate, Q

$$Q = 1.5 \text{ CFM/hen} \times 100,000 \text{ hens/bldg} = 150,000 \text{ CFM/bldg}$$

Converting Q from CFM to liter per hour by multiplying CFM value by 1,699,

$$Q = 150,000 \text{ CFM/bldg} \times 1,699 \text{ L/hr/CFM} = 254,850,000 \text{ L/(hr-bldg)}$$

**Step 2.** Absolute ambient temperature of the exhaust air,  $T_a$

First, converting air temperature from Fahrenheit to Celsius by the following equation:

$$^{\circ}\text{C} = (^{\circ}\text{F} - 32)/1.8 = (74 - 32)/1.8 = 23.33$$

Then, the absolute temperature is determined as,

$$T_a = ^{\circ}\text{C} + 273.15 = 23.33 + 273.15 = 296.5 \text{ }^{\circ}\text{K}$$

**Step 3.** Ambient barometric pressure,  $P_a$

At elevation of 1,000 ft above the sea, the nominal barometric pressure is 98 kPa, and is used in this calculation (if measured, use the actual value).

**Step 4.** Calculate NH<sub>3</sub> ER of the building by substituting the values into the ER equation:

$$ER = 254,850,000 \times (4 - 0) \times 10^{-6} \times \frac{17}{22.4} \times \frac{273.15}{296.5} \times \frac{98}{101.325} = 689 \text{ g/(hr-bldg)} \\ = 1.52 \text{ lb/(hr-bldg)}$$

## Resources

For a list of research reports, ISU Extension publications, and links to current news regarding air quality and animal agriculture, please visit the Air Quality and Animal Agriculture Web page at <http://www.extension.iastate.edu/airquality>.

Prepared by Hongwei Xin, professor, Department of Agricultural and Biosystems Engineering, Iowa State University. Edited by Jean McGuire, communications specialist, Iowa State University Extension, and designed by Donna Halloum, Creative Services, Instructional Technology Center, Iowa State University.

File: Environmental 4-1

The U.S. Department of Agriculture (USDA) prohibits discrimination in all its programs and activities on the basis of race, color, national origin, gender, religion, age, disability, political beliefs, sexual orientation, and marital or family status. (Not all prohibited bases apply to all programs.) Many materials can be made available in alternative formats for ADA clients. To file a complaint of discrimination, write USDA, Office of Civil Rights, Room 326-W, Whitten Building, 14th and Independence Avenue SW, Washington, DC 20250-9410 or call 202-720-5964.

Issued in furtherance of Cooperative Extension work, Acts of May 8 and June 30, 1914, in cooperation with the U.S. Department of Agriculture. Stanley R. Johnson, director, Cooperative Extension Service, Iowa State University of Science and Technology, Ames, Iowa.